PROAIM Vanguard Collapsible Utility Production Cart (CT-VNGD-UC5)

Assembly Manual



What's In The Box

Please inspect the contents of your shipped package to ensure you have received everything that is listed below.



Vanguard Cart



Spanner (Size:17 & 19mm)



2 x Wheels



2 x Brake Wheels

2 x O Rings



2 x O Rings (Extra)
Size: (3 x 70mm)

All rights reserved.

No part of this document may be reproduced, stored in a retrieval system, or transmitted by any form or by any means, electronic, mechanical, photo-copying, recording, or otherwise, except as may be expressly permitted by the applicable copyright statutes or in writing by the Publisher.

Vanguard **Setup**

Brake Wheel Installation


- Using a 19mm spanner, remove the bolts from the brake wheels.




- Remove the washer from the brake wheel.
- Insert the brake wheels into the Vanguard cart.




- The wheel rotates 360° for easy movement and fits seamlessly into the cart.

NOTE: The two front wheels swivel 360° for smooth rolling and steering on uneven surfaces. They include brakes for reliable parking. These air-free wheels prevent flats, and their textured design provides excellent grip on gravel, grass, and debris.



- Insert the washer into the brake wheel.
- Place the nut on the wheel.




- Tighten the bolt securely using a 19mm spanner.
- The brake wheel is now set in the Vanguard cart.




- Repeat the same process to install the other brake wheel.



Standard Wheel Installation

- Using a 17mm spanner, remove the bolt from the wheel.





- Insert the wheel into the Vanguard cart.





- Insert the bolt into the wheel and tighten it properly using a 17mm spanner.
- Repeat the same process for the other wheel.





NOTE: The cart offers maximum efficiency with a fully collapsible design, resilient wheels, impressive load capacity, and top-class craftsmanship.



Handle Operation

- Press the foot release bar with your foot and pull the handle to open the cart effortlessly.

NOTE: The handles collapse easily using the foot release bar, making the cart convenient to fit into car trunks.





- Repeat the process for the handle on the other side.

NOTE: The cart can haul up to 200 kg / 440 lb in a single go.




Extendable Cart Bed Setup

- Insert both knobs at the bottom of the cart and tighten securely.
- Adjusting the knobs allows you to extend or collapse the cart bed.




- Press the push pin and pull the cart in both directions to adjust the length.
- Tighten the knobs properly.

NOTE: The extendable bed allows the cart length to expand from 30" up to 52", accommodating larger loads.




O-Ring **Setup**

NOTE: If the O-ring is damaged, two extra O-rings are included for replacement.

- Remove the O-ring from the brake wheel using a 1.5mm Allen key (Not Included).




- Remove the O-ring from the top side.




- Insert the new O-ring manually by hand.




- The O-ring is now properly set in the brake wheel.



PROAIM VANGUARD COLLAPSIBLE UTILITY PRODUCTION CART
ALL DRESSED UP AND READY TO GO!



(SHOWN WITH OPTIONAL ACCESSORIES)

Warranty: We offer one year warranty for our products from date of purchase. Within this period of time, we will repair it without charge for labor or parts. Warranty doesn't cover transportation costs nor does it cover a product subjected to misuse or accidental damage. Warranty repairs are subjected to inspection and evaluation by us.

Liability: We are not liable for damage caused by products that we do not supply or from mishandling in transit, accident, misuse, neglect, lack of care of the product, or service by anyone other than our company.

Contact Us: In case of any kind of dissatisfaction, please Contact us immediately and we promise our utmost support and care until you use our product.